
TN 19.4.0.1: Scan Motion Monitoring (zTag-reading)

Release 2025.09

Heliotis AG

Aug 29, 2025

Contents

1	Challenge: Monitoring Scan Motion Profile	1
2	Implementation	2
3	Interpretation	3
4	Document History	4

1 Challenge: Monitoring Scan Motion Profile

For precise WLI measurements, it is essential that the measuring head moves at a well-controlled, constant speed with respect to the sample. Departures from this ideal case can occur due to sample movement (see Reducing-Vibration-Induced-WLI-Amplitude-Loss) or irregular scan stage motion. Detecting the latter for monitoring and optimization purposes is the subject of this technical note.

helilnspect devices keeps track of the motor stage position at the centre of each camera frame, see [Fig. 1.1](#). (In most operating modes, a surface and a reflectance image is extracted from the ensemble of these frames behind the scene.) The motor feedback, or more precisely the *motor encoder values*, can be retrieved as *zTags* from the same buffer as other measurements data.




Fig. 1.1: Illustration of heliInspect zTag Output Alongside In-Pixel Signal Processing

In every scan with a heliInspect, a stack of frames is recorded. Each individual frame represents the instantaneous envelope (and phase shift) of a high-frequency input signal in a spatially resolved manner. The camera also extracts the central motor position, or zTag, in terms of (integer) motor encoder increments for each frame. In most cases, these data are processed directly on the camera to determine the interpolated peak position, which corresponds to the surface position in every pixel. Other possible outputs of such processed extraction modes are the value of the envelope or the phase shift at the signal peak.

2 Implementation

To retrieve zTags, the camera must be configured to write them to the buffer containing measurement data as part of the so-called *chunk* components. Here are the corresponding instructions in the form of pseudo code.

Listing 2.1: Enable and Configure Chunk Data

```
# enable chunk data
ChunkModeActive = True
ChunkSelector = "ZTagCount"
ChunkEnable = True
# enable zTag related chunk data
ChunkSelector = "ZTagValue"
ChunkEnable = True
```

Note: This piece of code must be executed in the camera's configuration mode prior to the start of the data acquisition.

After the measurement, each frame's zTag can be retrieved by means of a loop.

Listing 2.2: Retrieving Device Data

```
# accessing zTags included in chunk data (part of acquired buffer)
nofZTags = ChunkZTagCount

zTags = array of size nofZTags
# loop over all available zTag values (index from 0 to nofZTags-1)
  ChunkZTagSelector = index
  zTags[index] = ChunkZTagValue
```

Note: This piece of code must be executed in the camera's acquisition after the buffer carrying data has been fetched.

Note: To properly terminate the loop, the number of zTags - or equivalently frames - is read directly from the buffer.

To convert the stage position of the i^{th} frame expressed as a zTag, $zTag[i]$, to physical units, they must be multiplied by the encoder resolution, Δ_{zTag} .

$$z[i] = zTag[i] \cdot \Delta_{zTag} \quad (2.1)$$

The encoder resolution can be read from the camera using the feature `EncoderResolution`.

Listing 2.3: Retrieving Encoder Resolution

```
# read encoder resolution in nm/tick
encoderRes = EncoderResolution
```

3 Interpretation

An example of one adequate and one inadequate outcome of the stage position monitoring are shown in Fig. 3.1.




Fig. 3.1: Satisfactory and Unsatisfactory Motion Profiles Measured via zTags and Converted to Physical Units In the former case, the scan parameters were selected to produce a linear, controlled stage movement. In the latter case a high ScanSpeed and a small AccelerationRamp were set. As a result, the scan speed is not yet stable during image acquisition, resulting in a non-linear movement.

4 Document History

Version	Date	Changes	Responsible
19.4.0.0	07-04-2025	Initial version	
19.4.0.1	11-06-2025	Review	bm